


Boxing Instructions to Return Two Model 57 / 55 Screens to Oehler for Repair

Save the original box and foam corners to return your screens for repair or refurbishment!



>1) Place screens with BNC connectors facing inside toward middle.

- 2) Rotate one screen facing upside-down, so BNC connectors are protected against damage.
 - 3) Place cardboard pad between screens for protection, place foam corners, and slide box over top. Box can then be tipped upright, and remaining foam corners inserted in other end. Securely tape box closed. There should be no movement of screens inside shipping carton.

Note BNC jack!

